

The Harp Shoppe Harp Trolley

Thank you for purchasing The Harp Shoppe Harp Trolley. This trolley was designed by a harpist for harpists. The Harp Shoppe Harp Trolley is made of light weight anodized aluminum with two sets of straps. We are sure it will make moving your harp easier and safer.

How to assemble your trolley:

Unpack box and separate pieces. Start with the wheel base and wheels. The trolley has a bicycle kick stand. Lower kick stand. (Note: When using your trolley, lower kick stand at all times when your harp is not on the trolley, always raise kick stand and then place your harp on the trolley.) Push up on the red tabs and insert wheel into base, repeat on the other side. Place silver push pins into arms on wheel base. Gently push handle down into the arms of the wheel base.

Strap assembly and adjustment:

The trolley comes with two sets of straps. The shorter set of straps is designed to wrap from the top of the handle and over the neck of the harp. Place harp on trolley and secure top strap around neck of harp. Adjust the straps to desired length by tightening the strap through the buckle. The bottom strap can go around the middle of the harp or at the base of the harp. Place strap above double padded beams for middle strap, or above wheel base for base strap. Adjust straps to fit your harp by tightening the strap through the buckle.

Extras:

The trolley comes with pneumatic tires and a tire pump. Packed with the pump is a metal peg and screw. This peg is for use ONLY with Camac harps. For Camac harps, install the peg into the hole closest to the edge of the scoop and tighten the screw to the bottom of the scoop. Push harp forward, slide the trolley under the harp. The peg will fit into the depression on the bottom of a Camac harp for added stability when moving the harp.

